



machine all around the bottom of the block
and machine a counter bore in gurile so to slip over block 1/2" deep

>>> > < too much gap !!!
2 bolts through the side
of the block to cap

> <
widen main cap on both sides
here and machine for tight fit